



# FXV-D >>>



Spare parts for cooling tower

## Fill, Coil & Pan Section

- i** 1. Spray branches
- i** 2. Spray branch grommets
- i** 3. Spray nozzles & nozzles grommets
- i** 4. Coil(s)
- i** 5. BACross 2 -  
Fill sheets with integrated drift eliminators
- i** 6. Drift eliminators
- i** 7. Combined inlet shields
- i** 8. Fan cylinder
- i** 9. Fan guard
- i** 10. Axial fan assembly (see detailed view)
- i** 11. Pump piping
- i** 12. Sleeve & clamps
- i** 13. Spray pumps  
with volute      without volute      seal kit
- i** 14. Make-up valve assembly
- i** 15. Float ball
- i** 16. Access door
- i** 17. Bleed line with manual valve
- i** 18. Pan strainers
- i** 19. Pan strainer hood
- i** 20. Heater
- i** 21. Low level cut out switch
- i** 22. Heater thermostat




**i** Gear box driven (option)

## Client contact information

Name \_\_\_\_\_  
 Company \_\_\_\_\_  
 Telephone \_\_\_\_\_  
 Email \_\_\_\_\_  
 Unit model \_\_\_\_\_  
 Serial number \_\_\_\_\_

## Your BAC contact

Name \_\_\_\_\_  
 Telephone \_\_\_\_\_  
 Email \_\_\_\_\_



## Axial fan assembly

- i** A. Axial fan
- i** B. Fan bushing
- i** C. Fan shaft
- i** D. Bearing with flinger collar
- i** E. Fan locking collar
- i** F. Bearing support
- i** G. Impervix Fan motor
- i** H. Drive set  
 Motor sheave & bushing  
 Aluminium fan sheave & bushing  
 Belt set



Quantities may vary according to the unit type.

This is not an official order form.

